



## SPC® Self- Install Instructions (CLEAR Plastic, Fiberglass, and Acrylic tub)

**\*\*Please follow installation instructions thoroughly\*\***

**Included in this kit is:**

1 roller handle  
1 roller tray  
1 roller  
Degreaser, Promoter, Thinner, Hardener, Clear Structure and Instructions

**Additional needs:**

Recommended mask  
1 roll of masking tape  
Teri cloth towels (for promoter application)  
Paper towels  
Plastic bag (for garbage)  
Knee pads

**\*\*To help with the smell we recommend running the bathroom fan or opening a window.\*\***

**\*\*Be sure to continually stir the material if sitting for any period of time\*\***

**Follow all safety instructions as defined in the MSDS sheets that are part of this kit.** If your MSDS sheets have become misplaced call 763-433-2903 or 1-800-878-0036 for free replacements.

**Remove all glue in strips and mats and any residual glue and gunk completely in all rooms.** *The tubs must be squeaky clean and without any glue residue. Ask your professional paint store for products that can help with the glue removal. Products that have worked well for us are GOOF OFF, and any other Non-flammable Adhesive Remover. We have found using our InViroSafe Heavy Duty Cleaner is helpful in removing dark spots and getting that clean surface. (remember that the tub needs to be squeaky clean).*

**Degrease #1- The tub using a kitchen paper towel.**

*Put some, NOT ALL degreaser on the paper towel and systematically wipe the tub bottom. (Will need degreaser again later) Place used paper towel in a plastic bag.*

**Using the *masking tape*, tape out a rectangle of about 14 by 30-inch in the tub bottom.**

*Wet Doesn't Mean Slippery*



www.SlipFix.com

763-972-9222

**Take a new paper towel and *degrease again* inside the area you just outlined with the tape.** Be sure to degrease over the tape edges while making sure that the tape is well attached to the bottom. *Place this paper towel in plastic bag. Do not touch the area to be treated with your bare hands. If you encountered any dripping taps, just put a bath towel under it to prevent drips from splashing on the area to be treated.*

**Put containers from the kit on your mixing workspace.**

**Open *Bottle 5 Clear Structure* and gently mix the contents with the stirring stick.**

*Do not shake the jar or mix in air bubbles.*

**Open *Bottle 3 Thinner* and pour into *container 5*.**

**Open *Bottle 4 Hardener* and pour into *container 5*.**

**Gently stir the structure with the stirring stick for 3 minutes. Do not whip in air during stirring.**

**Then pour contents of *container 5* in to tray.**

**Select *Bottle 2 Plastic Promoter* and apply inside the taped area on the bottom of the tubs.** This is done by saturating the terry cloth with the promoter and methodically wiping the area to be treated. Insure that there is complete coverage of the promoter. *Any area not coated with promoter will not hold the structure over time.*

**Note- The promoter must be allowed to sit for 5 to 10 minutes until the surface starts to look dull, then apply structure.**

**Stir again gently the mixed structure that is in the mixing cup and pour a little in the roller tray.**

**Place the roller on the roller handle using a glove and make sure it rolls freely. Do not touch the roller with bare hands!**

**Gently saturate the roller then roll of most it back in the tray. (*More is not better*)**

**Roll on the structure lengthwise and width wise twice in the tub while checking your work periodically with the flashlight. (*Just shine the flashlight***

*Wet Doesn't Mean Slippery*



www.SlipFix.com

763-972-9222

*over the SPC® to see the even spread of the structure.)*

**Remove the tape as soon as the SPC structure mix is rolled into the tub.**

*This will allow the structure to slightly flow out, nicely rounding of the edge, preventing buildup of dirt.*

-----

**Congratulations!!** You have completed the installation. The Rooms can be occupied the next day.

If you have any questions about the application of the SPC®, please feel free to call us at [info@SlipFix.com](mailto:info@SlipFix.com) or 763-972-9222.

**Thank you for using SlipFix Company SPC® Products.**

*Wet Doesn't Mean Slippery*