



SPT SELF INSTALLATION INSTRUCTIONS

- **DO NOT MIX PRODUCT WITH ANYTHING- JUST APPLY.**
- **(For outdoor applications)** it's best to apply non-slip in the morning or evening hours when the sun is not at its highest peak or on an overcast/cloudy day.
- There is no curing time, so you can walk on area as soon as application is finished.

Install equipment list:

For prepping floor: 1 deck brush (to scrub floor) 1 squeegee and or shop vac. Floor scrubbing machine with vac and squeegee attach will replace all of the above.

For applying non-slip: 1 hand pump sprayer (found at a hardware store such as Lowes or Home Depot)

Step 1: Sweep area off and use SPT Degreaser and hot water with a deck brush or power scrubber let it stand 1-2 minutes rinse with warm water. (Does not need to be dry before applying the non-slip- just be sure soapy suds are off and there is no standing water)

Step 2: Spray (common hand pump sprayer) SPT **non-slip** on degreased area, then take the deck brush and scrub area that was just sprayed with the Non-Slip. Be sure to split large areas smaller when applying non-slip. You want to keep the area you are applying the non-slip to saturated at all times, If the non-slip is drying between 10-15min. then just spray more SPT non-slip over the area. When area is covered you want to let it set for about 15-20min. (continue to step 3)

Step 3: After 15-20 minutes rinse with cold water (this will activate the non-slip) squeegee into drain or pick up with shop vacuum.

For questions and to order additional cleaner please contact us at: 763-972-9222 or help@SlipFix.com.

Wet Doesn't Mean Slippery